



OVER CLEAN MASONRY
 NO SURFACE PREPARATION IS NECESSARY
 PROVIDED THE SURFACE IS CLEAN AND
 FREE OF CONTAMINATES SUCH AS DIRT,
 DUST, RELEASE AGENTS, SEALERS, AND
 FORM OILS.
 NOTE : SEE CENTURION INSTALLATION
 PROCEDURES FOR REMOVING THESE
 CONTAMINATES.

Specifications :

APPLIED : PER CENTURION STONE
 VENEER INSTALLATION PROCEDURES
 REFERENCE ICC ES REPORT ESR-2239
 FOR SPECIFIC CODE REQUIREMENTS

NOTE 1 : WHEN INSTALLING STONE
 ON AN INHABITED AREA
 ONE MAY TO USE A WRB
 TO PREVENT MOISTURE
 FROM PENETRATING
 THE WALL

NOTE 2 : WHEN INSTALLING STONE
 ON UNHABITED AREAS SUCH
 AS ENTRANCES, RETAINING
 WALLS, AND AREAS NOT
 EFFECTED BY MOISTURE
 INTRUSION, THE WRB AND
 LATH MAY BE OMITTED

NOT TO SCALE



CENTURION
 STONE

Centurion Products, Inc
 50 Van Buren Street
 Nashville, TN 37208
www.centurionstone.com

STONE OVER CLEAN CMU WALLS

1.0.7