



SPECIFICATIONS:

ARCHED/HALF ROUND/ROUND WINDOWS USE A SELF-ADHERED FLASHING and or metal OR EQUAL.

INSTALLATION INSTRUCTIONS:

- A.
 1. install flanged window and Moisture Barrier based on manufacturers Installation Instructions

- B.
 1. install self-adhered flashing starting at bottom of window. Some Jurisdictions Call for Metal Flashing Rather than Self Adheared. Check Local Codes

 2. INSTALL ARCH STRIP FLASHING STARTING AT BOTTOM AND WORK YOUR WAY AROUND THE WINDOW COMPLETELY SEALING THE WINDOW TO THE SHEATHING.

 3. AFTER BOTH SIDES ARE RUN FROM BOTTOM TO TOP, THEN INSTALL ONE PIECE AT THE TOP

NOTE: THE SELF-ADHERED FLASHING IS TO EXTEND UPON TO THE WINDOW TO CREATE A TIGHT SEAL. (DO NOT EXTEND OVER ON TO THE FACE OF THE WINDOW.)

NOT TO SCALE



Centurion Products, LLC.
 7201 Cockrill Bend Blvd.
 Nashville, TN 37209
 www.CenturionStone.com

FLASHING AROUND CURVED WINDOW PERIMETER

D5