



**OVER CLEAN MASONRY:**

NO SURFACE PREPARATION IS NECESSARY PROVIDED THE SURFACE IS CLEAN AND FREE OF CONTAMINATES SUCH AS DIRT, DUST, RELEASE AGENTS, SEALERS, AND FORM OILS.

**NOTE:** SEE CENTURION INSTALLATION PROCEDURES FOR REMOVING THESE CONTAMINATES.

**SPECIFICATIONS:**

APPLIED: PER CENTURION STONE VENEER INSTALLATION PROCEDURES REFERENCE ICC ES REPORT ESR-2239 FOR SPECIFIC CODE REQUIREMENTS

**Options**

**NOTE 1:** WHEN INSTALLING STONE ON AN INHABITED AREA USE A WRB & Metal Lathe TO PREVENT MOISTURE FROM PENETRATING THE WALL

**NOTE 2:** WHEN INSTALLING STONE ON UNHABITED AREAS SUCH AS ENTRANCES, RETAINING WALLS, AND AREAS NOT EFFECTED BY MOISTURE INTRUSION, THE WRB AND LATH MAY BE OMITTED.

**Note 3:** Use of weep screed is optional

NOT TO SCALE



Centurion Products, LLC.  
7201 Cockrill Bend Blvd.  
Nashville, TN 37209  
www.CenturionStone.com

**STONE OVER CLEAN  
CMU WALLS**

F3